OLYLIS

GALAXY G-ONE

User Manual

Please read this manual carefully before use and keep it properly

Thank You for Choosing Our Product

Please read this manual carefully before use,
and keep it properly for future reference.

As the product continuously upgrades and improves, the content of the instruction manual for products of the same model may differ from the actual product in some details.

The illustrations shown in this manual are based on the standard model's appearance and are only used as demonstration. Please refer to the actual product you purchased for practical appearance.

Due to product improvements, some parameters may be changed, and the modified parameters are not retroactive to previous products. Please refer to the product brand parameters for accurate information.

Table Content

User Instructions/Precautions 01-03
Storage and Maintenance 04-05
Component Names 06
Product Operation Method 07
FAQ Solutions/Product Technical Specifications 08
Product and Spare Part Recycling Instructions 09
Battery Disassembly Instructions 10
Product Warranty Card 11
Product Certification 12

Important Information for Users

Symbol Description

To avoid personal injury or property damage, please make sure to follow the instructions below.

- The following icons indicate the actions to be taken

⊘ Indicates prohibition ❗ Indicates actions to be taken according to instructions

Not suitable for

❶ The following groups of people should use caution

- Individuals with severe peripheral nerve impairment due to diabetes
- Individuals with skin injuries
- Individuals with severe osteoporosis sunkness in their hands and feet
- Individuals with respiratory disorders
- Individuals with acute symptoms of visceral diseases (gastritis, hepatitis, nephritis)
- Individuals with vascular disorders
- Individuals using rehabilitation devices
- Individuals with implanted medical devices must be taken when used by
- Individuals who are too sensitive to heat
- Individuals who have undergone eye surgery should follow medical advice and wait for the recovery period after surgery. Prolonged use may prolong recovery time, or those who have had treatments in the past month causing skin irritation or swelling should consult a doctor before using this product.

⊘ The following group/situations are not suitable:

- Individuals undergoing strenuous exercise or stretching activities: Such as those with dizziness, severe arterial or venous diseases, acute venous diseases, serious skin inflammation, and skin infections, or using it immediately after exercise.
- Individuals with implanted devices like pacemakers or artificial hearts, inflammation or congestion in the head, discomfort symptoms like congestion, dizziness, and headaches after using the product.
- Patients with heart disease, severe cerebral thrombosis, those unsuitable for using the product without consulting a doctor, or those advised by a doctor to avoid use.
- Stroke patients, individuals with high or low blood pressure, those currently under medical treatment, and those feeling physically abnormal.
- Individuals with severe osteoporosis, those with bone metastasis, soft tissue diseases, malignant tumor patients, heart disease patients, and those with acute illnesses.
- Pregnant women and women during menstruation.
- Individuals with slow mobility, physical or mental discomfort, or intellectual disability.
- Children aged 3-14 and disabled individuals should use this product with assistance from others.
- Avoid use in high-temperature environments above 38℃.
- The heated surface may increase in temperature, so individuals sensitive to heat are advised not to use it.
- Individuals with open wounds, fractures, or burns on the skin or head should temporarily refrain from using this product.
- If experiencing body abnormal reactions such as back pain, dizziness, nausea, or discomfort, stop using immediately. After use, let the machine rest for 30 minutes to ensure its longevity.
- Do not use under the following circumstances:
  - Within 30 minutes after meals
  - Within 30 minutes before or after meals.
  - After consuming alcohol.

Usage precautions

❶ Do not use if the power cord is damaged.
❗ Stop using the product if you experience discomfort such as dizziness or headaches during use.
❗ Ensure that the power cord and plug are dry and kept away from heat sources.
❗ In case of damage to the power cord, for safety reasons, it must be replaced by professionals from the manufacturer, repair department, or a similar department.
⊘ Avoid operating control buttons with wet hands or splashing water onto the control panel during operation.
⊘ Do not allow children to play with or use the product unsupervised.
⊘ Do not use immediately after meals to avoid discomfort.
⊘ Do not use the product on sensitive areas such as the neck.
⊘ Do not drop or insert any objects into any openings.
⊘ Do not clean with gasoline, thinner, or similar substances, and do not spray directly onto it.
⊘ This product is for single-person use only; do not use by two or more persons simultaneously.
❶ Do not use if the power cord is damaged.
⊘ Do not damage, bend excessively, pull, twist, or bend the power cord.
⊘ Do not disassemble, repair, or modify the product on your own, as it may lead to malfunctions or electric shock accidents.
❗ If you notice any malfunction or abnormal condition during use, stop using it immediately.
⊘ Do not use a power source other than the rated voltage, and do not use if the appliance's casing is damaged.
⊘ Do not touch the metal charging contact while it is powered on.
❗ If you experience any unusual sensations in your body during use, stop immediately and consult a doctor.
⊘ Do not touch the metal panel with wet hands or plug/unplug the power plug with wet hands.
❗ After charging is complete, unplug the power plug from the power outlet and store it properly.

⊘ Do not smoke while using the product to prevent fire hazards.
⊘ Do not use on sunburn, bruised, or inflamed skin areas.
❗ If you experience very discomfort in the head or body, use the product under the advice of a doctor.

Usage precautions

⊘ Do not cover the product with towels, cloths, or other objects while in use.
⊘ Do not place it near heat sources like filled bathtubs, stoves, sinks, or other high-moisture areas.
⊘ Do not use in places where aerosol products or oxygen are used. Keep the product away from combustible gas and combustible materials.
⊘ Do not use the product in environments with temperatures exceeding 35℃ or where the temperature changes rapidly.
❗ If you see the message while driving in a high-temperature, humid environment.

Storage and Maintenance

Storage Conditions:

Transportation:
Suitable for general transportation vehicles but must be protected from severe impacts, vibrations, heavy pressure, intense sunlight exposure, and rain/snow exposure. Transportation should comply with the order contract.
Storage:
Store within an environmental temperature range of -10℃ to 45℃, relative humidity below 85%, and avoid direct sunlight exposure. Keep it away from humidity, ensure good ventilation, and no strong sunlight or corrosive gases.
Handling:
1.Do not use or plug the product for an extended period (over one month), store it in the packaging box.
2.Do not place the product in high-temperature, humid, steam-filled, or direct

sunlight environments.
3.Avoid subjecting the product to strong impacts or vibrations (such as dropping, throwing, or stepping).
4.Keep the product out of reach of children.
5.Store indoors with good ventilation and no strong sunlight or corrosive gases.

Storage and Maintenance

Maintenance Inspection:
Before using the product, the following checks should be carried out:
1.Check for any mechanical damage.
2.Check the accessories included.
3.Ensure the product's monitoring functions are working properly after turning it on.
If any abnormalities are found, do not use the product and promptly contact professional maintenance personnel. Any disassembly of the equipment must be done by professional maintenance personnel. Safety and maintenance checks can be performed by our staff.
Cleaning:
The product must be turned off and disconnected from the AC power before cleaning. Keep the product free from dust. Regularly clean the product, and if it gets dirty, use a damp cloth to wipe it. For stubborn stains, you can use a clean soft cloth dampened with water or a neutral detergent, wring it thoroughly, and then wipe the unit.
Maintenance and Storage Precautions:
1) Do not use strong solvents or other volatile agents such as acetone.
2) Avoid using abrasive materials (such as steel wool or other polish). Do not scratch the surface of the product with sharp objects.
Instructions for Replacing Replaceable and/or Removable Parts:
1.Normally, use the charging cable with the power adapter for charging. When the cable is damaged, it must be replaced by professional personnel. Use the same or equivalent type of power adapter recommended by us.
2.Using other power adapters not specified may result in product damage.

Component Names



Product operation method

1、Long press the(⏻)button to turn on the machine. It defaults to full-function massage mode and announces "Full-function massage".

2、Long press the(⏻)button to turn off the machine. It announces "Thank you for using, your session has ended".

3、In the power-on state, short press the(⏻)button to switch modes. The modes cycle in the following order and announces each mode as follows: "Full-function massage", "kneading and hot compress mode", "kneading and vibration mode", "massage and hot compress mode", "kneading mode", "vibration mode", "hot compress mode".

4、Short press the(⏻)button to switch between Chinese and English. The machine announces "中文模式 (Voice Prompt in Chinese) and "Voice Prompt in English". The default language is Chinese.

5、Long press the(⏻)button to turn the voice prompts on or off. The machine announces "Voice on" or "Voice off". When the voice prompts are off, pressing any button will not produce any sound.

Product Charging:
1、When charging, the green light indicates low battery. The machine announces "Low battery, please charge promptly", and the green light flashes While charging, the green light flashes. When fully charged, the green light stays on.
2、The machine cannot be used while charging.

Compatible Charging Methods:
1、Use the provided charging cable.
2、Connect to a computer USB port or power bank for charging.
Note:Do not use charging methods other than those listed above.

Product Specifications

Product Name	Eye Massager
Product Model	GALAXY G-ONE
Rated Input Voltage	3V ⎓
Rated Input Power	5W
Battery Capacity	1200mAh
Charging Time	≤3h
Usage Times per Full Charge	≥4
Defrost Session Time	15-minutes
Product Dimensions	210*115*31mm

Troubleshooting Guide

No.	Issue	Possible Cause	Solution
1	Product does not work	Product is charging	Use after charging is complete
		Power switch is off	Turn on the power switch
		Battery is low	Fully charge the product before use
2	Product stops during use	Auto timing finished	Wait 30 minutes and before using again
		Product is overheated (e.g. prolonged or at high ambients placed on it)	Reduce the load on the product

Product and Components Recycling Instructions

To protect the environment, after the product or its components are no longer usable, please do not dispose of them with other household waste and sending them to qualified recycling sites. Recycling stations will dismantle and recycle according to national regulations.

The correct disposal of hazardous substances is as follows:

部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
外壳组件	○	○	○	○	○	○
电子板	○	○	○	○	○	○
电线	○	○	○	○	○	○
加热片	○	○	○	○	○	○
硅胶眼罩	○	○	○	○	○	○
说明书	○	○	○	○	○	○
包装盒	○	○	○	○	○	○

○ 表示该有毒有害物质在该部件的均质材料中的含量低于GB/T 26572-2011规定的限量要求。
本表依据SJ/T 11364-2014的规定编制。
在现有的技术条件下，还没有可以替代铅、汞、六价铬、多溴联苯（PBB）、多溴二苯醚（PBDE）等有毒有害物质的材料。

Note
Please support the recycling of rechargeable battery (lithium battery).

Warning
1. Do not dispose of the product out of reach of children to prevent accidental swallowing.
2. In the case of accidental swallowing, consult the doctor immediately.
3. When the battery liquid leakage, do not touch the liquid with bare hand, and avoid contact with skin and eyes immediately.
4. When the battery fluid get into the eyes, it may cause blindness. Do not rub your eyes directly with your hands. Rinse immediately with clean water and consult a doctor.

Battery Disassembly Instructions

Note:
- according to regulations, the battery must be removed before discarding this product
- When removing the battery, the product must be disconnected from power. Ensure the battery is disposed of safely according to legal requirements.

Non-professionals should not attempt to disassemble the battery on their own!

Steps for Battery Disassembly:
1.Disconnect the external power supply and remove the product's outer cover.
2.Unplug the power from the battery.
3.Remove the battery.
4.Dispose of the battery at designated recycling points.
5.Please comply with local environmental protection laws and disposal guidelines to protect the environment.

Product Warranty Card

Warranty Terms:
1.Warranty period: The machine is warranted for one year from the date of purchase under normal usage conditions.
2.Warranty Exclusions: If the product exceeds the warranty period and requires free repair under normal usage, please bring this card and the invoice to the designated repair point for warranty service.
3.The following situations are not covered by free warranty but can be repaired at a fee:
1.Damage caused by improper use, maintenance, or storage by the consumer.
2.Damage caused by unauthorized disassembly by non-manufacturer repair personnel.
3.Lack of valid warranty card and invoice.
4.The warranty card does not match the repaired product model or has been altered.
5.Damage caused by force majeure.
4.Warranty Service Procedure: If repair is required, please keep them safe.
5.In addition to the repair matters specified in this warranty card, users with warranty issues should provide the purchase invoice and this warranty card to relevant national laws and regulations during the warranty period.

Product Name	
Place of Origin	
Warranty Period	
Invoice Number	
Purchase Date	

Maintenance Record		
Customer Information Date		
Customer Contact		
	Fault/Repair Handling Details	
Repair Facility		
Repair Technician Signature		

Product Certification

Cerification

Product Certification

Product Name: Eye Massager

Product Model: GALAXY G-ONE

Production Date:

Inspector:

Note:
In the manual, Failure to comply may exempt the company from assuming any responsibility for quality issues.

OLYLIS INTERNATIONAL PTE.LTD.

1 Jalan Kilang Timur,#01-02 Pacific Tech Centre,Singapore 159301.

OLYLIS

GALAXY G-ONE

使用说明书

使用前请仔细阅读本说明书,并妥善保管本说明书

感心感密选择本产品

感谢您购买我们的产品,为了保证您能顺利使用,请在使用前仔细阅读本说明书,并妥善保管,以备日后参考。

随着产品的持续更新与优化,本产品说明书内容可能会与实际产品有差异,请以实际产品为准。

本说明书提供的图片以标准型号的外观为基准,仅用于示例说明。请以您实际购买的产品外观为准。

由于产品改进,部分参数可能会变更,修改后的参数对本产品适用,而对以往产品不追溯效力。请以产品品牌参数为准。

目录

用户必读/注意事项 01-03
贮存与保养 04-05
产品部件介绍 06
产品操作方法 07
产品技术参数/常见问题解决办法 08
产品及零件回收说明 09
电池拆卸说明 10
产品保修卡 11
产品合格证 12

用户必读

符号描述

为避免造成人身伤害或财产损失,请务必遵守以下内容。

- 所以下图示表示相应所需遵守的内容。

⊘ 表示禁止 ❗ 表示需要根据指示执行

禁忌人群

❶ 以下人群应谨慎使用

有糖尿病神经损害严重者/有下肢肿胀人群、骨质工能表现会加重者/骨质疏松严重者

皮肤有伤口的人群

有呼吸系统疾病者

有内脏疾病急性症状者(胃炎、肾炎、肝炎)

有血管疾病的人群

使用康复设备的人群

植入医疗设备的人群

对热过于敏感的人群

处于术后恢复期的人群,术后恢复期建议遵从医嘱,术后恢复期间,如使用本产品,可能会延长恢复时间,或曾经有过皮肤刺激或肿胀的人群,在使用本产品前应咨询医生。

皮肤有外伤、烫伤、灼伤的人群

孕期及经期女性

行动不便的人群

儿童(3-14岁)及残障人士,应在成人协助下使用本产品。

- 所以下人群不适用:

- 在剧烈运动或伸展运动后立即使用的人群:如:有眩晕、动脉或静脉严重疾病、急性静脉疾病、皮肤有严重感染、伤口或疖肿的人群,或刚刚运动完毕的人群,建议暂缓使用。
- 有心脏病、脑血栓、高血压、低血压、正在接受医生治疗、身体感到异常的人群。
- 骨质疏松严重、有骨转移、软组织疾病、恶性肿瘤患者、心脏病患者、急性疾病患者。
- 孕妇及经期女性。
- 行动迟缓、身体、心理不适或智力障碍者。
- 3-14岁儿童、残障人士应在成人照顾下使用本产品。
- 禁止在38℃以上的环境下使用。
- 加热面温度可能会升高,对热敏感的人群请谨慎使用。
- 头部有伤口、骨折、烫伤、灼伤的人群,应暂时停止使用本产品。
- 使用过程中如出现不适症状,如:腰酸、眩晕、恶心、不适等,请立即停止使用。使用后,请静置30分钟,以确保产品的耐用性。
- 以下时间段不要使用:
  - 饭后30分钟内
  - 饭前、饭后30分钟之内
  - 喝酒之后

使用注意事项

⊘ 严格遵守产品说明书的使用注意事项

❗ 定期对加热导片进行清洁,以免影响加热效果。

- 以下人群/情况不适用:

- 有在剧烈运动或伸展动作后使用的人群:如:有眩晕、动脉或静脉严重疾病、急性静脉疾病、皮肤有严重感染、伤口或疖肿的人群,或刚刚运动完毕的人群,建议暂缓使用。
- 有心脏病、脑血栓、高血压、低血压、正在接受医生治疗、身体感到异常的人群。
- 骨质疏松严重、有骨转移、软组织疾病、恶性肿瘤患者、心脏病患者、急性疾病患者。
- 孕妇及经期女性。
- 行动迟缓、身体、心理不适或智力障碍者。
- 3-14岁儿童、残障人士应在成人照顾下使用本产品。
- 禁止在38℃以上的环境下使用。
- 加热面温度可能会升高,对热敏感的人群请谨慎使用。
- 头部有伤口、骨折、烫伤、灼伤的人群,应暂时停止使用本产品。
- 使用过程中如出现不适症状,如:腰酸、眩晕、恶心、不适等,请立即停止使用。使用后,请静置30分钟,以确保产品的耐用性。
- 以下时间段不要使用:
  - 饭后30分钟内
  - 饭前、饭后30分钟之内
  - 喝酒之后

使用注意事项

⊘ 严格遵守产品说明书的使用注意事项

❗ 定期对加热导片进行清洁,以免影响加热效果。

❗ 使用时请保持双手的清洁干燥,并远离热源

❗ 如果发现线缆损坏,为了保证安全,应由厂家或其维修部门或专业人员更换。

⊘ 禁止在通电状态下触摸充电接口

⊘ 禁止用湿手操作或插拔电源插头

⊘ 禁止将产品放在有水的容器内使用

⊘ 禁止将产品放在有易燃气体的场所使用,以免发生爆炸

⊘ 禁止将产品放在有易燃物品上使用,以免引发火灾

⊘ 禁止将任何物品塞入产品的孔洞

⊘ 禁止用汽油、稀释剂或类似物品清洁,也不要直接喷洗

⊘ 本产品仅限单人使用,不适合多人同时使用

❗ 使用过程中如出现不适症状,请立即停止使用。

❗ 使用前请先将产品放置30分钟,以确保产品的耐用性。

❗ 使用时请勿在饭后30分钟内使用,请在饭前或饭后30分钟内使用。

- 以下时间段不要使用:
  - 饭后30分钟内
  - 饭前、饭后30分钟之内
  - 喝酒之后

贮存与保养

储运条件:

运输:
长途/普通/特种运输,特别是要防止在运输过程中的剧烈冲击、振动、重压、强烈日照直接照射及雨雪侵蚀,运输过程应按合同规定。

储存:
贮存环境温度范围:-10℃~45℃,相对湿度不大于80%,大气压力范围:86kPa~106kPa,应通风良好,无腐蚀性气体和易燃及易爆物质。

搬运:
1.如长时间不使用本产品时,一个月以上,请放入纸盒中进行存储。
2.请小心产品包装盒,搬运,堆放,装卸及开箱时不要倒置。
3.搬运时,请轻拿轻放,不要随意抛掷,以免损坏产品的外观以及内部元件。
4.请妥善保管,以免儿童误用。
5.贮存在无腐蚀性物质,良好通风,无强烈日照,无腐蚀性气体和易燃易爆物质的场所。

部件名称



产品操作方法

中文模式

1、长按(⏻)键开机,默认为全功能按摩模式,播报"全功能按摩"。

2、长按(⏻)键关机,关机提示,播报"感谢您的使用,您的本次按摩已结束"。

3、开机状态下,短按(⏻)键切换模式,按按摩顺序,依次循环切换模式,并播报模式如下:"全功能按摩"、"热敷搓揉模式"、"振动搓揉模式"、"热敷按摩模式"、"搓揉模式"、"振动模式"、"热敷模式"。

4、短按(⏻)键切换中英文模式,播报"中文模式 (Voice Prompt in English)"、"Voice Prompt in English"。默认为中文模式。

5、长按(⏻)键开启/关闭语音提示,播报"语音开"、"语音关"。关闭语音提示后,按任意键无反应。

产品充电:
1、开机状态时,电量低,闪烁绿灯,播报"电量低,请及时充电"。充电时绿灯闪烁,充满后绿灯常亮。
2、充电时,不能开机使用。

适用充电方式:
1、使用TYPE-C充电线充电。
2、连接电脑USB口或移动电源进行充电。
注意:请勿使用上述方式以外充电方式充电。

产品技术参数

产品名称	眼部按摩器
产品型号	GALAXY G-ONE
额定输入电压	5V⎓
额定输入功率	5W
电池容量	1200mAh
充满电时间	≤3H
满电使用次数	≥4次
单次预计时间	15分钟
产品尺寸	210*115*31mm

常见问题解决办法

序号	现象	可能原因	处理方法
1	产品不工作	产品正在充电	充电完成后再使用
		电源开关关不	打开电源开关
		电池电量不足	充满产品后再使用
		静止工作时间到	间隔30分钟再开机使用
2	使用过程中停止	产品长时间高温(如用户将其放置等)	减轻产品负载

产品及零件回收说明

为了保护环境,产品或其中的部件超出其为消费者的使用年限或不再可用时,请勿将其与其他家庭垃圾一起丢弃,应将其送到合适的回收站点。回收站将按照国家法规进行拆解和回收。

正确处理有害物质的方法如下:

部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
外壳组件	○	○	○	○	○	○
电子板	○	○	○	○	○	○
电线	○	○	○	○	○	○
加热片	○	○	○	○	○	○
硅胶眼罩	○	○	○	○	○	○
说明书	○	○	○	○	○	○
包装盒	○	○	○	○	○	○

○ 表示该有毒有害物质在该部件的均质材料中的含量低于GB/T 26572-2011规定的限量要求。
本表依据SJ/T 11364-2014的规定编制。
在现有的技术条件下，还没有可以替代铅、汞、六价铬、多溴联苯（PBB）、多溴二苯醚（PBDE）等有毒有害物质的材料。

产品及附件注意事项

请支持回收可充电电池(锂电子电池)的回收物。

警告

1.请勿将7岁以每天吞咽量不超过每日耐受剂量(TDI)。以防止意外吞咽。
2.意外吞咽后,请立即咨询医生。
3.当电池泄漏时,请勿徒手接触液体,并防止与皮肤和眼睛接触。
4.当电池液进入眼睛时会造成失明的后果,请勿用手直接揉搓眼睛,需立即用清水清洗,并咨询医生。

电池拆卸说明

注意:
- 当您报废本产品时,应将其拆卸,并确保安全处置。
- 拆除电池时,产品必须断电。
- 电池回收需符合当地法规。

非专业人员请勿自行拆卸!

拆卸电池操作步骤
1.断开外部电源,并拆下产品外壳。
2.断开电池上的电源。
3.取出电池。
4.废弃电池应按照指定回收站点。
5.请遵守当地环境保护法律法规及废弃物处置,保护环境。

产品保修卡

保修规定:
1.保修期限:自正式购买之日起计算,保修期限为一年。
2.合规保修内容:正常使用情况下,因生产原因导致的质量问题或性能不达标,如果在保修期内,产品还在保修期内,您需凭此卡和发票进行保修服务。
3.不在保修范围内的情况:
a.人为损坏或拆卸、维修、改装产品造成的损坏。
b.非厂商授权或未经授权的维修。
c.缺乏有效保修卡和发票。
d.保修卡内容与产品型号不匹配或未加盖。
e.因不可抗力造成的损坏。
4.保修服务流程:如需维修,请妥善保管。
5.根据相关法规及国际惯例,在保修期内,因客户原因或因不可抗力导致的损坏,应按照相关规定收费。

产品名称	
产地	
保修期限	
发票号	
购买日期	

客户信息		
客户姓名		
联系方式		
故障描述及维修记录		
维修日期	维修内容	维修人员
维修技术员签名		

产品合格证

合格证

产品名称:眼部按摩器

产品型号:GALAXY G-ONE

生产日期:

检验员:

注意
本说明书中如有所出现非常规及其它正确使用方法,由公司保留不承担质量责任。

OLYLIS INTERNATIONAL PTE.LTD.

1 Jalan Kilang Timur,#01-02 Pacific Tech Centre,Singapore 159301.